FiiO

快速入门指南
Quick Start Guide

Model: FX7221

Note: X7 Mark Ⅱ is hereinafter referred to as X7

Buttons and Ports labeled/Operation explained

3.5mm Lineout/Coaxial/Optical output   Power/Lockscreen

Pause/Play

Volume wheel

Change tracks
(Previous track/
Next track)

Micro SD card
slot 1

Micro SD card
slot 2

Touch screen
(with screen
protector applied
in factory)

Interchangeable
headphone
amplifier module

Note: X7 Mark Ⅱ is hereinafter referred to as X7

Power on/off

Hold the Power button to turn on the X7. Click the preferred language onscreen and then the confirm button to enter main UI. Hold the Power button while X7 is on, a shutdown dialogue will pop up, and you can select to power off or reboot the player.

Charging

Both the normal charge and quick charge are supported. It's recommended to use a charger with DC9/12V to shorten the charging time.

Used as a USB DAC connecting with computer

Please download the USB DAC driver on our website and follow relevant instructions to install and use X7 as a USB DAC.

Download link：http://www.fiio.net/en/supports

Firmware upgrade

1、Over-the-air automatic firmware update

Turn on the X7's WiFi and connect to a hotspot connected to the internet, the X7 will detect it automatically. If no firmware update detected, please click "Technical support -> Firmware Update -> Online Upgrade" to check and upgrade manually.

2、Manual update via update zip file

Please download firmware on our website and follow relevant instruction to upgrade.

Download link: http://www.fiio.net/en/supports

Notes and precautions

★ Do not repair or disassemble the product by yourself or put it in water.

★ If the X7 is to be left unused for a long time, please recharge the unit periodically to preserve its battery life.

★ You might not able to hear the sound of the surroundings when using headphones. For your safety, please avoid using headphones in dangerous situation.

★It's recommended to use suitable charger in case of high-voltage adaptor causing damage to the X7

★ In the likely event that the X7 hangs up, you may hold the power button for 15 seconds to force a reboot.

Note: X7 Mark Ⅱ is hereinafter referred to as X7

Accessories (please confirm if the following items are included)
1、Tempered glass screen protector*1 (applied on X7 in factory)
2、USB cable*1
3、Coaxial adaptor cable*1
4、T5 screw*4
5、Screwdriver*1
6、Leatherette case*1
7、Warranty card*1
8、Quick start guide*1
9、Hi-Res mark sticker*1
10、Ejector pin*1
11、Clear case*1

To learn more about FiiO products, please go to
http://www.fiio.net/en/fiio. To learn more about operating your FiiO product,
please go to http://www.fiio.net/en/supports and download the detailed User
Guide corresponding to your model.

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated
as household or general waste. It should be handed over to the
applicable collection point for the recycling of electrical and
electronic equipment, or returned to the supplier for disposal.

Internal/Supplied Batteries
This symbol on the battery indicates that the battery is to be collected
separately. This battery is designed for separate collection at an appropriate
collection point.

Qualcomm aptX is a product of Qualcomm Technologies
International, Ltd.
Qualcomm is a trademark of Qualcomm Incorporated,
registered in the United States and other countries, used
with permission. aptX is a trademark of Qualcomm
Technologies International, Ltd., registered in the United
States and other countries, used with permission.