FiiO

快速入门指南
Quick Start Guide

型号：M11

Buttons and Ports Labeled/Operation Explained

Power/Lockscreen

Play/Pause

Volume wheel

Previous track

Next track

Micro SD card slot 1

Micro SD card slot 2

4.4mm balanced output
2.5mm balanced output
USB transfer/Charging port
3.5mm Headphone/Lineout/Coaxial output

Power on/off

Hold the Power button to turn on the M11. Click the preferred language onscreen to enter main UI. Hold the Power button while M11 is on, a shutdown dialogue will pop up, and you can select to power off or reboot the player.

Charging

It takes about 2 hours to complete a full charge with a Quick charger 2.0 (DC 12V/1.5A) . To achieve the ideal charging, it's recommended to use a charger with Quick charger 2.0 or above.

Gestures

Return to Previous Level: swipe right from the left edge of the screen, or swipe left from the right edge.
Return to Home: swipe up from the bottom edge of the screen.
Multi-task Management: swipe up from the bottom edge of the screen and then hold.

Used as an USB DAC connecting with computer

Please download the USB DAC driver on our website and follow relevant instructions to install and use M11 as an USB DAC.
Download link：http://www.fiio.com/supports

Firmware upgrade

1. Over-the-air automatic firmware updates

Turn on the M11's WiFi and connect to a hotspot connected to the internet, the M11 will detect it automatically. If no firmware update detected, please click "Technical support -> Firmware Update -> Online Upgrade" to check and upgrade manually.

2. Manual update via update zip file

Please download firmware on our website and follow relevant instruction to upgrade.
Download link: http://www.fiio.com/supports

Notes and precautions

★Do not repair or disassemble the product by yourself and put it in water.
★Please charge the battery on a regular basis to secure the battery life if no use of it for long time.
★You might not able to hear the sound of the surrounding when using headphones. For your safety, please avoid using headphones in dangerous situation.

★It's recommended to use suitable charger in case of high-voltage adaptor causing damage to the M11.

★In the likely event that the M11 hangs up, you may hold the Power button and Play/Pause for 10 seconds to force a reboot.

Accessories (please confirm if the following items are included)

1. Tempered glass screen protector*1 (applied on M11 in factory)
2. USB cable*1   3. Coaxial adaptor cable*1
4. Warranty card*1   5. Quick start guide*1
6. Clear case*1   7. Ejector pin*1

To learn more

To learn more about FiiO products, please go to http://www.fiio.com. To learn more about operating your FiiO product, please go tohttp://www.fiio.com/supportsand download the Complete User Manual corresponding to your model.

WEEE Directive & Product Disposal

At the end of its serviceable life,this product should not be handed as household or general waste.It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Internal/Supplied Batteries

This symbol on the battery indicates that the battery is to be collected separately. This battery is designed for separate collection at an appropriate collection point.

Qualcomm aptX is a product of Qualcomm Technologies, Inc. and/or its subsidiaries.Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries.

aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries.

LDAC and LDAC logo are trademarks of Sony Corporation.   Qualcomm aptX™ HD